


## Frost Top Installation FAQ Sheet

Below are the steps to install the frost top with the manual and spec sheet attached below.

- 1. Define the cabinet space needed to house the frost top.
- 2. Factor in a break/seam between the hidden warming area and the hidden frost top space: minimum 11 inches.
- 3. Cut substrate/underlayment to allow the frost top to drop into the opening.
- 4. Make sure the underlayment opening is routed to allow the frost top flange to rest flush on the underlayment.
- 5. Review that the top of the frost top is flush with the top of the underlayment.
- 6. Apply the thermal mastic to the frost top and then apply standard mastic to the substrate/underlayment before the material is set in place.
- 7. Ensure the chilling plate of the Frost Top makes <u>even contact</u> with the underside of the counter top material.
- 8. Wait one and a half days before using the system.
- 9. Warranty of components and labor for 60 days, components only for 1 year from delivery.



Common questions regarding counter installation and design...

- Are all solid surface brands or granites acceptable materials for the counter tops? -Yes, as long as they are a minimum of ¼ inch thick and a max of 1 and 1 ¼ inch.
- Is there any brand or material other than marble that should not be used?
   -We recommend: Smartstone, Ceasarstone, Silestone, Cambria or any other sealed or non-porus granite.
- Is there a certain distance from the frost top that a break or seam in the material should be?
  - -Minimum is about 11 inches.
- Any specific sealants or silicones that should be used?
   -KEIL Thermal Mastic
- Is there factory installation that we can specify?
   -Call Spring USA at 800-535-8974 for clarity
- When specifying a remote refrigeration unit what is the maximum distance that the compressor can be?
  - 50 Ft
- Would it be possible for you to send us an installation manual for our files?
   See attached documents below, frost top spec sheet and installation/service manual

Frost Top Spec Sheet
Frost Top Installation/Service Manual



**Hidden Frost Top Opening**(Routed to allow the frost top flange to rest flush on the underlayment)



**Hidden Frost Top Pre-Install** 



**Finished Product**